Facing and Boring Heads

UPA



WORLIAUPTER

Für Ihren Erfolg.

Universal Facing and Boring Heads

For use on universal milling and boring machines, jig borers etc. suitable for all types of work in single or series production.

Product range UPA 3 to UPA 5-S 6

UPA 3, 4 and UPA 5-S6 are only delivered with screw-on tool shanks (DS)

UPA 3

- Working range: Ø 0 260 mm
- Slide adjustment: 48 mm
- Almost every type of shank, for tapers from ISO 30 and from MT 3, can be fitted to the UPA head



UPA 4

- Working range: Ø 0-400 mm
- Slide adjustment: 52 mm
- Almost every type of shank, for tapers from ISO 40 and from MT 4, can be fitted to the UPA head



UPA 5-S 6

- Working range: Ø 0−620 mm
- Slide adjustment: 112 mm
- Almost every type of shank, for tapers from ISO 40 and from MT 5, can be fitted to the UPA head





Technical data

| Type and size | | | UPA 5-S 6 | |
|--|--|--------------|------------------------|--|
| | with rapid return in the same direction of revs. | ' | ave a lengthened slide | |
| Working accuracy, mm | ± 0.005 | ± 0.005 | ± 0.005 | |
| Types of possible shanks: | 20.000 | | 2 0.000 | |
| mm Ø | 25 | 35 | 45 | |
| MT | 3 | 4 | 5 | |
| ISO | 30 | 40 | 40 | |
| Metric | - | _ | - | |
| Facing and boring range, mm in Ø | 0 – 260 | 0 – 400 | 0 – 620 | |
| Adjustment of slide, max. mm | 48 | 52 | 112 | |
| Self activated feed of slide | 0.0507 | 0.02 0.04 0 | .06 0.08 0.10 0.12 | |
| per rev. in mm | 0.0507 | 0.14 0.16 0. | .18 0.20 0.22 0.24 | |
| Fine adjustment: | | | | |
| 1 division mm in Ø | 0.01 | 0.01 | 0.01 | |
| 1 revolution mm in Ø | 1.0 | 0.4 | 0.4 | |
| Rapid return per revolution, mm in Ø | 1.0 | - | - 1 | |
| Rapid return setting per revolution, mm in | n Ø – | 6.0 | 6.0 | |
| Largest dia. of slide, mm | 85 | 115 | 170 | |
| Height of head without shank, mm | 75 | 128 | 128 | |
| Tool locations in slide, mm Ø | 18 | 22 | 22 | |
| Weight of head (without shank), kg | 2.1 | 6.5 | 7.9 | |
| Max. permissible revolutions | 1000 | 600 | 600 | |
| End cut off accuracy | ± 0.05 | ± 0.05 | ± 0.05 | |

Chip production values

| Guide for chip | cutting | | | Туре | e and | size | | | |
|----------------|--|---------|-------|-------|-------|------|-----|---------|------|
| | | | UPA 3 | ı | UPA 4 | 1 | ι | JPA 5- | -S 6 |
| b_ | Max. load | KW | 2.5 | | 7.0 | | | 9.5 | |
| | With slide feed | mm/rev. | 0.050 | 0.08 | 0.12 | 0.24 | 0.0 | 3 0.12 | 0.24 |
| | For smaller working Ø | d₁, mm | 60 | | 150 | | | 200 | |
| | Max. width of chip | b, mm | 4 | 7 | 6 | 4 | 8 | 7 | 5 |
| | Max. working Ø | d₁, mm | 260 | | 400 | | | 500 / 6 | 620 |
| Max. width | Without reinforcement rings | b, mm | 2 | 2.2 | 2 | 1.5 | 2. | 5 2 | 1.5 |
| of cip | With reinforcement rings ¹⁾ | b, mm | _ | 4.5 | 4 | 3 | 5 | 4 | 3 |

¹⁾ By using the reinforcement rings, contained in the normal attachment, chip cutting capacity is increased by 100%.

Operation

UPA 3

Facing:

For facing, the feed of the slide is engaged with the feed button and the holding ring is stepped with the holding bar. This controls – while machine spindle is revolving – the facing feed. Slide travel can be preset with stops. When the stop reaches the fixed pin, the facing feed stops automatically. When the rapid return button is pressed, – which can also be done while the machine spindle is rotating, the slide returns to the starting position. This button can also be used for stopping the facing feed at any time.

Boring:

The setting in general and the feed for cylindrical internal and external boring is done by scale ring. After feed-in the slide is clamped by the clamping screw.

Taper Turning:

For this operation, the feed of head and machine feed must be at the correct ratio.

- 1 Stop
- 2 Fixed pin
- 3 Feed button
- 4 Scale ring
- 5 Holding ring
- 6 Return button
- 7 Holding bar
- 8 Adjusting screw
- 9 Slide with bores for tool location



UPA 4 / 5-S 6

Facing:

For facing, press drive pin and stop holding ring with the holding bar. 12 different facing feed steps can be set by feed button (from 0.02 – 0.24 mm/rev.). One sets facing feed while machine spindle is revolving. The feed can be set with the stop. When the stop reaches the fixed pin, the facing feed stops automatically. The return setting or the rough feed of the slide is set by the quick setting spindle with the operating key.

Boring:

The slide setting for cylindrical turning (internal and external) is achieved by either using the quick setting spindle or the fine setting spindle. After bringing the slide forward, it is clamped with the clamping screw.

Taper Turning:

For taper turning and when cutting conical threads, the feed of the head and machine feed must be at the correct ratio.



Thread Cutting:

When thread cutting on machines with suitable axial feed, the cutting tool is adjusted with the fine setting spindle and lifted with the quick setting spindle.

- 1 Stop
- 2 Fixed pin
- 3 Fine setting spindle
- 4 Feed buttons
- 5 Release ring
- 6 Feed ring
- 7 Adjusting screw
- 8 Ring
- 9 Drive pin
- 10 Holding bar
- 11 Quick setting spindle
- 12 Slide with tool location bores



Storage boxes for Facing and Boring Heads and Attachments

Boxes to fit the following types of shank:

UPA 3 with screw-on shank

MT 3, MT 4, ISO 30 or ISO 40

UPA 4 and with screw-on shank
UPA 5-S 6 to MT 5, ISO 40, ISO 50



Tool location

The boring heads UPA 3 up to UPA 5 – S6 are only supplied with DS-connection (detachable shanks). These can be used without reservation, for right or left turning. The mounting is done by a differential thread pin and no important parts need removing.


There are two cylindrical pins for the turning moment drive. For the mounting of the tool shank to the facing and boring head the following must be observed: When mounting, turn the operational key to the left, when releasing, turn key to the right.



Applications


WOHLHAUPTER Facing and Boring Heads

The universal tool for working in single parts or work in series.




Examples - Application of the attachments -






Boring and facing with short boring bar holder and a boring bar




directly in slide

Recessing with short boring bar holder and a boring bar




boring bar

Because of the small construction of the facing and boring heads deep bores can be made. In this case the boring bit is fixed directly in the slide.




Facing of large Ø with long boring bar holder reinforced by rings and draw in screw.






Facing in two areas with one boring bar and a boring bar holder




Facing of the reverse side by using boring bar holders contained in attachment

Application Examples - with special tool holder -



Multiple use for production in series:
Facing, boring, recessing and chamfering by using special tool holder, fixed in the facing and boring head.




For work on slanted areas with a conical angle of 120° – 180°, the usual type of UPA head can be provided with a slanting flange. For single application a special tool holder is mounted on the slide.

Facing and Boring Head UPA 3

The universal tool for facing, boring, recessing, thread cutting and for special work, for use on universal milling machines, jig borers, boring machines etc.

Working range: Ø 0 – 260 mm



| | Weight, kg | Order Number |
|--|------------|--------------|
| Facing and boring head UPA 3 (as fig. 1) | 2,1 | 005 020 |

The facing and boring head (fig. 1) is arranged for mounting DS-tool shanks (fig. 2). Because shanks can be exchanged, this facing and boring head can be used on machines with different spindle locations. With each tool shank a differential thead pin and an operation key is supplied. When mounting, the instructions on mounting sheet No. 102 200 should be followed.

| DS-tool shanks, fig. 2 | | | | Weight, kg | Order Number | No. | of drawings |
|---|---------------------|---------|-----------|------------|------------------|-----|-------------|
| MT 3 x Tang (M 12 unsci | rewable) | | DIN 1806 | 0.4 | 130 001 T00 4509 | K | 9674 |
| MT 4 x Tang | | | DIN 1806 | 0.6 | 130 001 T00 3590 | K | 9462 |
| MT 4 x M 16 | | | DIN 2207 | 0.7 | 130 001 T00 4256 | K | 9461 |
| MT 4 x M 14 | SIP | | | 1.0 | 130 001 T00 4255 | K | 9843 |
| MT 5 x Tang | (OERLIKON) | | DIN 1806 | 1.4 | 130 001 T00 3920 | K | 9358 |
| Collet location R8 | BRIDGEPORT | | | 0.5 | 130 001 T00 7166 | K | 9532 |
| ISO 30 x M 12 | | | DIN 2080 | 0.4 | 130 001 T00 3673 | K | 9466 |
| ISO 40 x M 16 | | | DIN 69871 | 1.0 | 130 001 T01 3815 | K | 14150 |
| ISO 40 x M 16 cap screv | v clamping | | DIN 2080 | 1.0 | 130 001 T00 3703 | K | 9469 |
| ISO 40 x ⁵ / ₈ in. – 11 BSV | V | similar | DIN 2080 | 0.9 | 130 001 T00 4498 | K | 9906 |
| ISO 50 x M 24 | | | DIN 2080 | 2.8 | 130 001 T00 3704 | K | 9470 |
| ISO 50 x 1 in 8 BSW | | similar | DIN 2080 | 2.7 | 130 001 T00 4480 | K | 9912 |
| Norm taper 40 x S 20 x 3 | 2 with bolts DECKEL | | | 1.0 | 130 001 T00 5070 | K | 8620 |
| ISo 40 x M 16 (chucking | g groove) | | DIN 2080* | 0.8 | 130 001 T01 0229 | K | 10246 |
| ISO 50 x M 24 (chucking | groove) | | DIN 2080* | 2.8 | 130 001 T01 0048 | K | 10069 |

^{*} with chucking groove

Other types of shanks on demand



Accessories

Boring bars

| Boring depth, mm | Designation | l₁, mm | Order No. |
|------------------|-------------|--------|-----------|
| 30 | B 306 | 60 | 073 003 |
| 60 | B 309 | 90 | 073 004 |
| 90 | B 312 | 120 | 073 005 |



Boring bar holders

| Working Ø, mm | Designation | l₁, mm | Order No. |
|---------------|-------------|--------|-----------|
| 85 – 190 | BH 308 | 82 | 075 001 |
| 160 – 260 | BH 312 | 120 | 075 002 |



Square turning bits HSS

| Designation | s, mm | I ₁ , mm | Order No. |
|-----------------|-------|---------------------|-----------|
| VD 6 (4 pieces) | 6 | 40 | 089 001 |



Clamping sleeves

| Designation | d ₁ , mm | Order No. |
|-------------|---------------------|-----------|
| SP 308 | 8 | 071 103 |
| SP 310 | 10 | 071 104 |
| SP 312 | 12 | 071 105 |
| SP 314 | 14 | 071 106 |



Tool box

| Designation | Order No. |
|-----------------|-----------|
| Tool box HK 311 | 099 007 |




1 Set of accessories

| consisting of | Order No. |
|---|-----------|
| Boring bars / boring bar holders /square turning bits / | |
| clamping sleeves / service key | 100 040 |

Facing and Boring Head UPA 4

The universal tool for facing, boring, recessing, thread cutting and for special work, for use on universal milling machines, jig borers, boring machines etc.

Working range: Ø 0 – 400 mm



| | Weight, kg | Order Number |
|--|------------|--------------|
| Facing and boring head UPA 4 (as fig. 1) | 6.5 | 007 020 |

The facing and boring head (fig. 1) is arranged for mounting DS-tool shanks (fig. 2). Because shanks can be exchanged, this facing and boring head can be used on machines with different spindle locations. With each tool shank a differential thead pin and an operation key is supplied. When mounting, the instructions on mounting sheet No. 102 221 should be followed.

| DS-tool shanks, fig. 2 | | | Weight, kg | Order Number | No. of drawing |
|---|---------|-----------|------------|------------------|----------------|
| MT 4 x Tang | | DIN 1806 | 0.9 | 130 005 T00 3590 | K 9511 |
| MT 5 x Tang (OERLIKON) | | DIN 1806 | 1.6 | 130 005 T00 3920 | K 9321 |
| ISO 40 x M 16 | | DIN 69871 | 1.5 | 130 005 T01 3815 | K 14180 |
| ISO 40 x M 16 cap nut clamps | | DIN 2080 | 1.2 | 130 005 T00 3703 | K 9518 |
| ISO 40 x ⁵ / ₈ in. – 11 BSW | similar | DIN 2080 | 1.2 | 130 005 T00 4498 | K 9531 |
| ISO 50 x M 24 | | DIN 2080 | 2.9 | 130 005 T00 3704 | K 9519 |
| ISO 50 x 1 in. – 8 BSW | similar | DIN 2080 | 2.9 | 130 005 T00 4480 | K 9914 |
| Norm taper 40 x S 20 x 2 with bolts DECKEL | | | 1.2 | 130 005 T00 5070 | K 8622 |
| ISO 40 x M 16 | | DIN 2080* | 1.2 | 130 005 T01 0229 | K 10248 |
| ISO 40 x ⁵ / ₈ in. – 11 BSW | similar | DIN 2080* | 1.2 | 130 005 T01 0327 | K 10334 |
| ISO 50 x M 24 | | DIN 2080* | 3.0 | 130 005 T01 0048 | K 10071 |

^{*} with chucking groove

Other types of shanks on demand

WOULD PTER

Für Ihren Erfolg.

Accessories

Boring bars

| Boring depth, mm | Designation | I₁, mm | Order No |
|------------------|-------------|--------|----------|
| 45 | B 408 | 85 | 073 006 |
| 85 | B 412 | 125 | 073 007 |
| 125 | B 416 | 165 | 073 008 |



Boring bar holders

| Working-Ø, mm | Designation | I ₁ , mm | Order No. |
|---------------|-------------|---------------------|-----------|
| 115 – 240 | BH 410 | 98 | 075 003 |
| 220 – 400 | BH 418 | 180 | 075 004 |



Square turning bits HSS

| Designation | s, mm | I ₁ , mm | Order No. |
|-----------------|-------|---------------------|-----------|
| VD 6 (4 pieces) | 6 | 40 | 089 001 |



Reinforcement rings and fixing parts

| Designation | l ₁ , mm | Order No. |
|-------------|---------------------|-----------|
| VR 401 | 10 | 077 100 |
| VR 402 | 20 | 077 101 |
| VR 403 | 30 | 077 102 |
| VR 404 | 40 | 077 103 |
| Screw | | 077 104 |
| Disc | | 077 105 |



Clamping sleeves

| Designation | d ₁ , mm | Order No. |
|-------------|---------------------|-----------|
| SP 408 | 8 | 071 107 |
| SP 410 | 10 | 071 108 |
| SP 412 | 12 | 071 109 |
| SP 414 | 14 | 071 110 |
| SP 418 | 18 | 071 111 |



Tool box

| Designation | Order No. |
|-----------------|-----------|
| Tool box HK 411 | 099 008 |




1 Set of accessories

| consisting of: | Order No. |
|---|-----------|
| Boring bars / boring bar holders /square turning bits / | |
| reinforcement rings / clamping sleeves / service key | 100 041 |

Facing and Boring Head UPA 5-S6

The universal tool for facing, boring, recessing, thread cutting and for special work, for use on universal milling machines, jig borers, boring machines etc.

Working range: Ø 0 – 620 mm



| | Weight, kg | Order Number |
|--|------------|--------------|
| Facing and boring head UPA 5 (as fig. 1) | 7.9 | 013 020 |

The facing and boring head (fig. 1) is arranged for mounting DS-tool shanks (fig. 2). Because shanks can be exchanged, this facing and boring head can be used on machines with differing spindle locations. With each tool shank a differential thead pin and an operation key is supplied. When mounting, the instructions on mounting sheet No. 102 201 should be followed.

| DS-tool shanks, fig. 2 | | Weight, kg | Order Number. | No. of drawings |
|---|----------------|---------------|-----------------|-------------------|
| MT 5 x Tang (OERLIKON) | DIN 18 | | 130 005 T00 392 | 20 K 9321 |
| ISO 40 x M 16 | DIN 69 | 9871 1.5 | 130 005 T01 381 | 15 K 14180 |
| ISO 40 x M 16 cap nut clamps | DIN 20 | 080 1.2 | 130 005 T00 370 | O3 K 9518 |
| ISO 40 x ⁵ / ₈ in. – 11 BSW | similar DIN 20 | 080 1.2 | 130 005 T00 449 | 98 K 9531 |
| ISO 50 x M 24 | DIN 20 | 080 2.9 | 130 005 T00 370 | O4 K 9519 |
| ISO 50 x 1 in. – 8 BSW | similar DIN 20 | 080 2.9 | 130 005 T00 448 | 80 K 9914 |
| Norm taper 40 x S 20 x 2 with bolts DECKEL | | 1.2 | 130 005 T00 507 | 70 K 8622 |
| ISO 40 x M 16 | DIN 20 |)80* 1.2 | 130 005 T01 022 | 29 K 10248 |
| ISO 40 x ⁵ / ₈ in. – 11 BSW | similar DIN 20 |)80* 1.2 | 130 005 T01 032 | 27 K 10334 |
| ISO 50 x M 24 | DIN 20 | 80* 3.0 | 130 005 T01 004 | 48 K 10071 |

^{*} with chucking groove

Other types of shanks on demand



Accessories

Boring bars

| Boring depth, mm | Designation | I ₁ , mm | Order No. |
|------------------|-------------|---------------------|-----------|
| 45 | B 408 | 85 | 073 006 |
| 85 | B 412 | 125 | 073 007 |
| 125 | B 416 | 165 | 073 008 |



Boring bar holders

| Working-Ø, mm | Designation | I ₁ , mm | Order No |
|-----------------------|-------------------|---------------------|----------|
| 120 – 400 | BH 513 | 128 | 075 005 |
| 270 – 620 | BH 523 | 230 | 075 006 |
| for extemded assembly | BH 410 (2 pieces) | 98 | 075 003 |



Square turning bits HSS

| Designation | s, mm | l ₁ , mm | Order No. |
|-----------------|-------|---------------------|-----------|
| VD 6 (4 pieces) | 6 | 40 | 089 001 |




Reinforcement rings and fixing parts

| Designation | l ₁ , mm | Order No. |
|-------------|---------------------|-----------|
| VR 401 | 10 | 077 100 |
| VR 402 | 20 | 077 101 |
| VR 404 | 40 | 077 103 |
| VR 407 | 70 | 077 108 |
| Disc | | 077 105 |
| Screw | | 077 109 |
| Screw | | 077 110 |




Clamping sleeves

| Designation | d ₁ , mm | Order No. |
|-------------|---------------------|-----------|
| SP 408 | 8 | 071 107 |
| SP 410 | 10 | 071 108 |
| SP 412 | 12 | 071 109 |
| SP 414 | 14 | 071 110 |
| SP 418 | 18 | 071 111 |



Tool box

| Designation | Order No. |
|-----------------|-----------|
| Tool box HK 511 | 099 009 |




| consisting of: | Order No. |
|---|-----------|
| Boring bars / boring bar holders /square turning bits / | |
| reinforcement rings / clamping sleeves / service key | 100 044 |



Clamping holder for replaceable inserts

The clamping holders with round shank are for facing and boring and are fixed directly in the slide of the facing and boring heads or in the boring bar holders



| Form and application | | Boring range | | | Measurements | | Order No. |
|---|---|--------------------|--------------------|----------------|----------------|---------|-----------|
| | | Ø min. | boring head | d ₁ | l ₁ | r_1 | |
| hold | Right hand clamping | 27 | UPA 3 | 18 | 80 | 13.5 | 081 087 |
| | holder 95°: - for boring - for facing from | 27 | UPA 4 and UPA 5-S6 | 22 | 100 | 13.5 | 081 092 |
| | | | | | | | |
| inside to outside | | | | | | | |
| Left hand clamping holder 95°: - for hub boring - for facing from outside to inside | Left hand clamping | 27 | UPA 3 | 18 | 80 | 13.5 | 218 088 |
| | 27 | UPA 4 and UPA 5-S6 | 22 | 100 | 13.5 | 218 089 | |
| | | | | | | | |
| Right hand clamping holder 80°: - for boring | Right hand clamping | 27 | UPA 3 | 18 | 80 | 13.5 | 081 088 |
| | | 27 | UPA 4 and UPA 5-S6 | 22 | 100 | 13.5 | 081 093 |
| | | | | | | | |
| | Right hand clamping holder 80°: for facing from inside to outside | 27 | UPA 3 | 18 | 80 | 7.5 | 081 089 |
| | | 31 | UPA 4 and UPA 5-S6 | 22 | 100 | 7.5 | 081 094 |
| | | | | | | | |

Replaceable inserts

Replaceable insert form 103 you find in our catalog Replaceable inserts 90200.

Cutting tools

Order No.

Blank of cutting tool VD 6/0 for UPA 3, UPA 4 and UPA 5-S6

HSS
089 100
Hard metal¹⁾
091 100

¹⁾ When ordering please indicate apart from the ordering code also the HM quality, e.g. K 10, P 20, M 10.

WORLER

Für Ihren Erfolg.

UPA 3



UPA 4



UPA 5-S 6



Wohlhaupter Programm Wohlhaupter range Le programme Wohlhaupter

WOHLHAUPTER Systemwerkzeuge System tools Système d'outils






















WOHLHAUPTER

Für Ihren Erfolg.

Wohlhaupter GmbH Präzisionswerkzeuge

Maybachstraße 4 Postfach 1264

72636 Frickenhausen 72633 Frickenhausen Tel. +49 (0)7022 408-0 Fax +49 (0)7022 408-212 www.wohlhaupter.com E-Mail: info@wohlhaupter.de